

## LAB ONE Comfort Cushion

### Filling Process

Filling material : expanded micro-polystyrene balls  $\varnothing$  2 mm fire-proof, 1 B class

Filling Process :

- 1° the internal cover is filled with a volume of micro-polystyrene corresponding to +/- 1,3 Kg ( +/- 45 liters ).  
N.B. microballs are electrostatic.
- 2° Sew the Zip on the internal cover (white) with straight stitches, to avoid an unexpected opening of the cushion.

See below pictures of the sewing method.

